



Installation Instructions

SLC 5/03, SLC 5/04, and SLC 5/05 Modular Processors

Catalog Numbers 1747-L531, 1747-L532, 1747-L533, 1747-L541,
1747-L542, 1747-L543, 1747-L551, 1747-L552, 1747-L553

http://literature.rockwellautomation.com/idc/groups/literature/documents/in/1747-in009_-mu-p.pdf

FR

Cette publication est disponible en français sous forme électronique (fichier PDF). Pour la télécharger, rendez-vous sur la page Internet indiquée ci-dessus.

IT

Questa pubblicazione è disponibile in Italiano in formato PDF. Per scaricarla collegarsi al sito Web indicato sopra.

DE

Diese Publikation ist als PDF auf Deutsch verfügbar. Gehen Sie auf die oben genannte Web-Adresse, um nach der Publikation zu suchen und sie herunterzuladen.

ES

Esta publicación está disponible en español como PDF. Diríjase a la dirección web indicada arriba para buscar y descarga esta publicación.

PT

Esta publicação está disponível em português como PDF. Vá ao endereço web que aparece acima para encontrar e fazer download da publicação.



SLC 5/03, SLC 5/04, and SLC 5/05 Modular Processors

Catalog Numbers 1747-L531, 1747-L532, 1747-L533
1747-L541, 1747-L542, 1747-L543,
1747-L551, 1747-L552, 1747-L553

Topic	Page
Safety Considerations	5
Hazardous Location Considerations	5
Required Tools and Equipment	7
Install the SLC Processor	7
Apply Power to the Processor	8
Loading Your Software	9
Establish Communication to the Processor	9
Replace the Battery	10
Troubleshooting Your SLC Processor	12
Specifications	12
Communication	13
Memory Backup	14
Battery Handling, Storing, and Transporting (Cat. No. 1747-BA)	14
Additional Resources	16

Important User Information

Solid state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls (publication SGI-1.1.1 available from your local Rockwell Automation sales office or online at <http://literature.rockwellautomation.com>) describes some important differences between solid state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.

WARNING 	Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.
IMPORTANT	Identifies information that is critical for successful application and understanding of the product.
ATTENTION 	Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you to identify a hazard, avoid a hazard, and recognize the consequences.
SHOCK HAZARD 	Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.
BURN HAZARD 	Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.

Safety Considerations

ATTENTION



Never install, remove, or wire any module while power is applied. Also, do not expose processor modules to surfaces or other areas that may typically hold an electrostatic charge. Electrostatic charges can alter or destroy memory.

For general recommendations concerning installation safety requirements and safety related work practices, refer to the requirements specific to your region.

- Europe: Reference the standards found in EN 60204 and your national regulations.
- United States: refer to NFPA 70E, Electrical Safety Requirements for Employee Workplaces.

IMPORTANT

See page 14 for information on proper battery handling, storage, and transporting.

Hazardous Location Considerations

This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only. The following WARNING statement applies to use in hazardous locations.

WARNING



EXPLOSION HAZARD

- Substitution of components may impair suitability for Class I, Division 2.
- Do not replace components or disconnect equipment unless power has been switched off or the area is known to be non-hazardous.
- Do not connect or disconnect components unless power has been switched off or the area is known to be non-hazardous.
- This product must be installed in an enclosure. All cables connected to the product must remain in the enclosure or be protected by conduit or other means.
- All wiring must comply with N.E.C. article 501-4(b).

Environnements dangereux

Cet équipement est adapté à une utilisation en environnements de Classe I, Division 2, Groupes A, B, C, D ou dans des environnements non dangereux. La mise en garde suivante porte sur une utilisation en environnement dangereux.

AVERTISSEMENT



DANGER D'EXPLOSION

- La substitution de composants peut rendre cet équipement impropre à une utilisation en environnement de Classe I, Division 2.
 - Ne pas remplacer de composants ou déconnecter l'équipement sans s'être assuré que l'alimentation est coupée et que l'environnement est classé non dangereux.
 - Ne pas connecter ou déconnecter des composants sans s'être assuré que l'alimentation est coupée et que l'environnement est classé non dangereux.
 - Ce produit doit être installé dans une armoire. Tous les câbles qui lui sont connectés doivent rester dans l'armoire ou être protégés par un conduit ou par d'autres moyens.
 - L'ensemble du câblage doit être conforme aux normes d'électricité en vigueur dans le pays où l'appareil est utilisé.
-

Required Tools and Equipment

- medium blade screwdriver
- programming equipment
- appropriate network interface or cable

Cable Requirements

Network Interface	Processor		
	SLC 5/03	SLC 5/04	SLC 5/05
1747-UIC	X ⁽¹⁾	X ⁽⁴⁾	X ⁽⁴⁾
1747-PIC	X		
1747-CP3	X	X	X
1784-PKTX(D)	X ⁽²⁾	X	
1784-PCMK	X ⁽³⁾	X ⁽⁵⁾	
10/100Base-T Ethernet			X

- ⁽¹⁾ requires 1747-C13 or 1747-CP3 cable
- ⁽²⁾ requires 1784-CP14 cable
- ⁽³⁾ requires 1784-PCM4 cable
- ⁽⁴⁾ requires 1747-CP3 cable
- ⁽⁵⁾ requires 1784-PCM6 cable


Install the SLC Processor

Make sure system power is off; then insert the processor into slot 0 of the 1746 chassis.

IMPORTANT

The SLC 500 modular processors must be inserted into the left slot (slot 0). Inserting the processor in another slot won't allow the processor to operate.

In addition, remove the protective wrap after installing the processor. Failure to remove the wrap can cause the power supply to overheat.




Apply Power to the Processor

1. Energize the chassis power supply.
2. Check the chassis power supply and processor LED indicators. The power LED indicator on the power supply should be on and the fault LED indicator on the processor should be flashing.


See the figure on page 9 for location of the power supply and processor LED indicators.

Power Supply and LED Indicators




SLC 5/03

- ☐ Indicates the LED indicator is OFF.
- ☒ Indicates the LED indicator is ON.
- ☐ Indicates the LED indicator is FLASHING.
- ☐ Status of LED indicator does not matter.



SLC 5/04



SLC 5/05

Loading Your Software

Refer to your programming software documentation.

Establish Communication to the Processor

1. Refer to the following table to establish communication between the processor and your personal computer.

Processor	Procedure
SLC 5/03	Connect the 1747-PIC interface from the processor to your personal computer serial port or connect the 1747-UIC interface from the processor to your personal computer USB port to the processor using the 1747-C13 or 1747-CP3 cable. You can also use a 1784-PKTX(D) or 1784-PCMK interface, or a 1747-CP3 cable from channel 0 of the processor to the personal computer serial port.
SLC 5/04	Connect a 1747-CP3 cable from channel 0 of the processor to the personal computer serial port or connect the 1747-UIC interface from channel 0 of the processor to your personal computer USB port, or use a 1784-PKTX(D) or 1784-PCMK interface.
SLC 5/05	Connect a 1747-CP3 cable from channel 0 of the processor to the personal computer serial port, or connect the 1747-UIC interface converter from channel 0 of the processor to your personal computer USB port. For Ethernet connection, connect channel 1 of the processor and the PC Ethernet Card to an Ethernet hub using 10/100Base-T compatible cable. ⁽¹⁾

⁽¹⁾ EtherNet/IP address must first be set via BOOTP or an RS-232 connection.

2. Set the communication parameters of the software to match the default parameters of the processor.

Channel 0 Configuration		Channel 1 Configuration	
SLC 5/03, 5/04, 5/05	SLC 5/03	SLC 5/04	SLC 5/05
DF1 Full-duplex: - no handshaking 19.2 Kbaud - CRC Error Check - duplicate detect on - no parity	DH-485: 19.2 Kbaud - node address = 1	DH+: 57.6 Kbaud - node address = 1	Ethernet: BOOTP enabled

Replace the Battery

Your SLC processor provides back-up power for RAM through a replaceable lithium battery. This battery provides back-up for approximately 2 years. The BATT LED indicator on the front of the processor alerts you when the battery voltage has fallen below a threshold level.

To replace the lithium battery follow these steps.

ATTENTION



Do not remove the processor from the SLC 500 chassis until all power is removed from the SLC 500 power supply. If you remove the power supply while power is applied, an electrical arc can occur. This could cause an explosion in hazardous location installations.


1. Remove power from the SLC 500 power supply.
2. Remove the processor from the chassis by pressing the retainer clips at both the top and bottom of the module and slide it out.

ATTENTION



Do not expose the processor to surfaces or other areas that may typically hold an electrostatic charge. Electrostatic charges can alter or destroy memory.

3. Unplug the battery connector.

**IMPORTANT**

The SLC 5/03, 5/04, and 5/05 processors have a capacitor that provides at least 30 minutes of battery back-up while the battery is disconnected. Data in RAM is not lost if the battery is replaced within 30 minutes.

4. Remove the battery from the retaining clips.
5. Insert a new battery into the battery retaining clips.
6. Plug the battery connector into the socket as shown above.
7. Re-insert the module into the SLC 500 chassis.
8. Restore power to the SLC 500 power supply.
9. Close the processor door.

IMPORTANT

See page 14 for information on proper battery handling, storage, and transporting.

Troubleshooting Your SLC Processor

Before troubleshooting your SLC 500 system, please obtain an SLC 500 Modular Hardware Style User Manual, publication 1747-UM011. Refer to the chapter on troubleshooting.

In addition to the SLC 500 Modular Hardware Style User Manual, publication 1747-UM011, the SLC 500 Instruction Set Reference Manual, publication 1747-RM001, contains explanations and examples for the entire instruction set as well as for all status words and bits. It also contains explanations for all possible fault codes found in status word S:6.

Specifications

SLC 5/03, SLC 5/04, and SLC 5/05 Processors

Attribute	SLC 5/03			SLC 5/04			SLC 5/05		
	L531	L532	L533	L541	L542	L543	L551	L552	L553
Memory (words)	8 K	16 K	32 K	16 K	32 K	64 K	16 K	32 K	64 K
I/O capacity, max	4096 discrete inputs/4096 discrete outputs								
Local system, max	3 chassis / 30 slots								
Programming instructions	107								
Typical scan time ⁽¹⁾	1 ms/K			0.9 ms/K					
Bit execution (XIC)	0.44 μs			0.37 μs					
Programming software	SLC 5/03s and SLC 5/04s: RSLogix 500, SLC 5/05s: RSLogix 500								

⁽¹⁾ The scan times are typical for a 1 K ladder logic program consisting of simple ladder logic and communication servicing. Actual scan times depend on your program size, instructions used, and the communication protocol.

Specifications

Attribute	Value
Power supply loading at 5V dc	500 mA for the SLC 5/03 processor
	1.0 A for the SLC 5/04 and 5/05 processors
Power supply loading at 24V dc	175 mA for the SLC 5/03 processor
	0 mA for the SLC 5/04 processor ⁽¹⁾
	0 mA for the SLC 5/05 processor
Program scan hold-up time after loss of power	20 ms...3 s (dependent on power supply loading)
Noise immunity	NEMA Standard ICS 2-230
Vibration	Displacement: 0.015 in., peak-to-peak at 5-57 Hz
	Acceleration: 2.5 g at 57...2000 Hz
Shock, operating	30 g
Ambient temperature rating, operating	0...60 °C (32...140 °F)
Ambient temperature rating, storage	-40...85 °C (-40...185 °F)
Humidity	5 to 95% without condensation
Agency certification See http://ab.com for declarations of conformity, certificates, and other certification details.	UL Listed Industrial Control Equipment C-UL Listed Industrial Control Equipment for use in Canada UL Listed Industrial Control Equipment for use in Class I, Division 2, Hazardous Locations Groups A, B, C or D CE compliant for all applicable directives C-Tick marked for all applicable acts

⁽¹⁾ SLC 5/04 Processors manufactured prior to April 2002 draw 200 mA at 24V dc. Check your label to verify your processor's current draw.

Communication

Communication options for the SLC 5/03, 5/04, and 5/05 processors are as follows:

- DH485
- RS-232 protocols (DF1 Full-duplex, DF1 Half-duplex master/slave, DF1 Radio Modem, DH-485, or ASCII)
- Data Highway Plus (A ControlLogix Gateway is required for the SLC 5/03 and SLC 5/05 processors.)
- Ethernet TCP/IP (A 1761-NET-ENI interface module is required for the SLC 5/03 and SLC 5/04 processors)
- ControlNet (via a 1747-KFC15 module)
- DeviceNet (via a 1761-NET-DNI interface module)