

Table 8–1 CCU control components replaceable by customer (continued)

Component name	Product number	SAP number	Serialized	Special tasks in case of replacement
Current Transducer	UUD148AE02	3BHE014185R0002	x	Set jumpers according to electrical drawings
Industry PC	Compact 7M2	3BHE035578R0001	x	-

8.3.2. Replaceable control components in POU

Table 8–2 POU control components replaceable by customer

Component name	Product number	SAP number	Serialized	Special tasks in case of replacement
PECINTM	PC D237 A101	3BHE028915R0101	x	-
IPS	IPS21-24V	3BHE032593R0001	x	-
HVD	XV C770 BE102	3BHE021083R0102	x	-
VLSCD	XV C724 BE	3BHE009017R0102	x	-
ASE2B	UD C920 BE102	3BHE034863R0002	x	-
AC/DC Converter	QUINT-PS/3AC/24DC/40	3BHE031065R0001	x	Set voltage according to electrical drawings
DC/DC Converter	QUINT-PS-24DC/24DC/10	3BHB057230P2424	x	Set voltage according to electrical drawings
UPS	QUINT-DC-UPS/24DC/40	3BHB056371P0040	x	Set time and battery dial according to electrical drawings
Battery	QUINT-BAT/24DC/7.2Ah	3BHB056372R0002	x	-

8.3.3. Replaceable control components in FIU

Table 8–3 FIU control components replaceable by customer

Component name	Product number	SAP number	Serialized	Special tasks in case of replacement
AC/DC Converter	QUINT-PS/1AC/24DC/10	3BHE016113R0110	x	Set voltage according to electrical drawings